



Remove the Old Spray Head

- ☐ Remove the old spray head and screen from the hose.

Install the New Spray Head

- ☐ Determine which type of hose is included with your particular faucet.

NOTE: If the hose has an O-ring use the all-metal screen, if not you will use the rubber-rimmed screen.

- ☐ **For all-metal screen installations:** Carefully insert the screen into the threaded end of the spray head.
- ☐ **For rubber-rimmed screen installations:** Place the screen on the end of the hose.
- ☐ **For all installations:** Thread the spray head onto the hose. Do not overtighten.

USA: 1-800-4-KOHLER
Canada: 1-800-964-5590
Mexico: 001-877-680-1310
kohler.com

© 2004 Kohler Co.

1038631-9-**A**